



BATTERY TESTER AND DEPASSIVATOR

APPLICATIONS

- Battery Monitoring
- Battery Depassivations

FEATURES

- Easy to Use
- Verify Battery Voltage
- Depassivate Lithium Batteries
- Robust Design

INSTRUCTIONS

1. Connect battery to Battery Tester with provided Lemo connector.
2. Press and hold “TEST” button to display battery voltage.
3. To Depassivate, press and hold “DEPASS” button while also holding “TEST” button.
4. After Depassivating, press and hold “TEST” again. If the red light illuminates, the battery should not be used



Warning: Measuring battery voltage will not provide an indication of the capacity of the battery cells. Battery capacity can be determined by keeping careful records of the batteries usage and exposure to temperature over time.
